

Oklahoma One-Call System, Inc.

2831 N.W. 59th Street
Oklahoma City, OK 73112-7005
405-840-9955











www.callokie.com

For all the latest news and information

APWA Uniform Color Code

For marking underground utility lines

	Proposed Excavation
	Electric Power Lines, Cables, Conduit and Lighting Cables
	Gas, Oil, Steam, Petroleum, or Gaseous Materials
	Communications, Alarm, CATV, Signal Lines, Cables or Conduit
	Potable Water
	Reclaimed Water, Irrigation and Slurry Lines
	Sewers and Drain Lines
	Temporary Survey Markings

GPS
GeoCall

When calling in a locate, give Call Okie the latitude, longitude or the legal description for your dig site. If possible provide a starting point such as a major intersection.



Call 1-800-522-OKIE
(1-800-522-6543)

The call center is open 24 hours a day, 7 days a week.

Summary of the Law



Call before you dig 1-800-522-OKIE

- Call 48 hours before you dig. Emergencies must be called in as soon as possible.

Wait the required amount of time

- Call at least two days, but no more than 10 days excluding Sat. & Sun. and legal holidays prior to excavation.
- Member utilities will mark the approximate location of their facilities within 48 hours or communicate to the excavators they have no facilities in the proposed excavation site.

Respect the marks

- Update your request if work is not started within 10 working days or if marks are no longer visible.
- The safety zone is a strip of land two (2) feet on either side of the underground facility. Remember to include the width of the facility!



Dig with care

- If digging within the safety zone, you must determine the precise location of the underground facility by digging test holes by hand.
- In case damage occurs, notify the operators of the underground facilities immediately! If the damage permits the escape of hazardous gas or liquid, you must also notify the police and the fire department immediately.
- Excavators must delay backfilling in the damage area until repairs are made.

Short list of required information for the call center

- Work date and time
- Type of work
- Excavator company and caller contact information
- County, city (or nearest town if rural)
- Specific directions to the work site and nearest intersection
- Who is the work being done for
- Duration of work